

Crimped joints for Cu and Al connectors, and the importance of thermography for preventive maintenance

Guidance information

[Information within brackets in this document refers to local regulations]

These instructions deal with bolt connections/crimped joints for connections in copper and aluminium conductors and the importance of thermography for preventive maintenance. The instructions discuss a number of fundamental concepts in this field and give advice and guidelines for planning and execution. While the instructions do not claim to be complete or exhaustive, they may in some contexts serve as a valuable tool for the electrical engineer. The figures given have been mainly taken from Elpress with their permission.

This edition differs from the previous one mainly through a general review of the document has been made.

Contents

- 1 Introduction**
 - 1.1 System engineering
 - 1.2 Economy
- 2 Connections - crimping**
 - 2.1 Control
 - 2.2 Connectors, copper
 - 2.3 Connectors, aluminium
 - 2.4 Product coding
 - 2.5 Tool systems
 - 2.6 Safety/Control
 - 2.7 Environmental tolerance and temperature
 - 2.7.1 Standard
 - 2.7.2 Tough environments
 - 2.8 Crimping, small areas
 - 2.9 Bolt connections
 - 2.9.1 Connections
 - 2.9.2 Marking
 - 2.9.3 Safety/inspection
 - 2.10 Mounting of bolted joints for cable shoes in general
- 3 The importance of thermography in preventive maintenance**
 - 3.1 General
 - 3.2 Methods of splicing
 - 3.2.1 Fixed joints
 - 3.2.2 Moving contacts
- 4 References**